Instruction




084R9168

Pressure Transmitter MBS 1800

Please refer to the table below for the pin allocation.





Pin	4 - 20 mA	0.5 - 4.5 V
1	GND	GND
2		
3	Output 418 mA	
4	(Com. Input)*	(Com. Input)*
5	-	Output 0.54.5 V
6	(Com. Output)*	(Com. Output)*
7	(Drift Comp. Off)*	(Drift Comp. Off)*
8	Supply 1232 V	Supply 1232 V
× 111 f		

^{*} Used for production purposes

Shielded cables must be used, grounded at controller end.



